

Echo 9 Ultra Cleaning Kit Instructor...

1. Turn Water OFF. Remove nozzle or tubing from the top adapter.
2. Turn the unit to lay on the left side.
3. Attach acid water shut off valve in off position (horizontal to tubing).
4. Reconnect acid line (you can keep shut off valve in place for future use).
5. Squeeze 12.5 ml of the cleaning solution into the top adapter.
6. Let solution sit like this for 1 hour.
7. After 1 hour, quickly turn on and off the H2 water function about 3-4 times. **DO NOT LET SOLUTION STAND OVER 1 HR.**
8. Turn the unit back to the upright position.
9. Turn the shut off valve to the on position parallel to tubing).
10. Turn the water to the unit back on.
11. Let your water run for about 1 minute on Alkaline level 1.
12. Turn acid line back ON for normal function.
13. If unit does not clear. Repeat above steps.



Connect the shut off valve to the acidic elbow.



Lay unit on left side and insert cleaning solution nozzle into top spout.



Reconnect your acidic line to the shut off valve for future use.